



## ***How to Install***

**Step 1. Place arch over window opening being sure that it is centered and the bottom is at the correct location.**

**Step 2. Insert screw (#6 sheetrock) at top of arch, into pre-drilled mounting hole making sure not to over tighten.**

**Step 3. Place a level at the bottom of the arch and ensure that it is properly aligned.**

**Step 4. Insert remaining screws (supplied).**

**Step 5. Place button caps (supplied) over screw holes and push in as far as possible by hand. Use a small hammer to lightly tap in the rest of the way being careful not to damage the button cap.**

**Step 6. Use a mild window cleaner to remove any fingerprints or dirt. Do not spray directly onto arch or rub hard as this could damage the paint.**